



Installing Your Sliding Doors

- 1** Unpack your doors and lay them out to orient the grain pattern-- the finger holes should be on the outside, left and right. You may choose either edge as “up”.
- 2** Once the table is mounted to the wall, you will simply lift the doors up into the top grooves and then lower into the bottom grooves. Start with the back groove first, then proceed to the front groove for the second door.
- 3** The doors are meant to be tight fitting, and due to seasonal wood movement, may be tricky to get in, especially the back groove. Ask a friend to help by applying moderate pressure and “flex” the wood to open slightly while you pop in the doors. It’s best to try this in the center of the open space rather than on the left or right side.
- 4** The doors should now slide smoothly over the entire space. When closed, the wood grain on the doors should match and be continuous.
- 5** Enjoy!



Problems + Questions
INFO@KROVELMADE.COM

Checkout Our Install Video
KROVELMADE.COM/INSTALL